



## **Firmware update SM3300-series**

### **Release notes**

Before updating the firmware, always consult the release notes.

For an overview of all the changes, see the firmware release note.

[Products > SM3300 > Downloads > Firmware > Release notes](#).

### **How to update an SM3300-series power supply**

1. Consult the update instructions. Download the latest manual from the website:  
[Products > SM3300 > Downloads > Manuals > Product Manual SM3300 series](#).  
  
Go to the product manual and follow the instructions in chapter 4.2.1, on page 8.
2. Download the latest firmware update from the website:  
[Products > SM3300 > Downloads > Firmware > Firmware update SM3300 series](#).
3. Start the update process