



## Firmware update SM15K

### How to update your SM15K?

1. Read the update instructions. Download the latest manual from the website:  
[Products > SM15K > Downloads > Manuals > Product Manual SM15K series.](#)  
Go to the product manual and follow the instructions in chapter 7.4, on pages 24 and 25.
2. Download the latest firmware update from the website:  
[Products > SM15K > Downloads > Firmware > Firmware update SM15K series.](#)

### Need to upgrade first?

**Attention!** Check if the current firmware version is P0109 or older (lower than P0109).

If so, upgrade the unit first. The upgrade is firmware version: P0119.  
After upgrading from P0109 to P0119 you can proceed with the P0151 update.

### Release note

For an overview of all the changes, see the firmware release note.

[Products > SM15K > Downloads > Firmware > Release notes.](#)